

# Regulus

[www.regulus.eu](http://www.regulus.eu)



EcoAir 614M / 622M


Installation and Operation Manual  
**CTC EcoAir 614M / 622M**  
Modulating air-to-water heat pump

EN

**EcoAir 614M / 622M**

## Table of Contents

<b>Safety instructions</b> .....	<b>3</b>	6.1 General information, electrical connections .....	20
<b>Checklist</b> .....	<b>4</b>	6.2 Electric installation 400 V 3N~ .....	20
<b>1. Technical data</b> .....	<b>6</b>	6.3 Compressor heater .....	20
1.1 Sound pressure data .....	6	6.4 Heat pump connections .....	20
1.2 Dimensions diagram .....	7	6.5 Connecting the control system .....	21
1.3 Refrigerant system .....	8	6.5.2 Connection options for several heat pumps	
1.4 Operating range .....	8	CTC EcoAir 600 .....	21
1.5 Component location .....	9	6.6 Alarm output .....	22
<b>2. Connection alternatives</b> .....	<b>11</b>	6.7 Wiring diagram 400 V 3N~ (A4) .....	23
<b>3. Important to remember!</b> .....	<b>12</b>	6.8 Wiring diagram 400 V 3N~ (A3) .....	24
3.1 Transportation .....	12	6.9 Parts list .....	26
3.2 Positioning .....	12	6.10 Sensor Data .....	27
3.3 After commissioning .....	12	<b>7. First start</b> .....	<b>28</b>
<b>4. Installation</b> .....	<b>13</b>	<b>8. Operation and Maintenance</b> .....	<b>28</b>
4.1 Delivery includes: .....	13	<b>9. Troubleshooting/appropriate measures</b> .....	<b>30</b>
4.2 Placement of the heat pump .....	14	<b>EU Declaration of conformity</b> .....	<b>31</b>
4.3 Preparation and drainage .....	15		
4.4 Condensation water .....	16		
<b>5. Pipe installation</b> .....	<b>17</b>		
5.1 Pipe connection .....	17		
5.2 Example of connection to			
CTC EcoZenith i350 L .....	18		
5.3 Circulating pump – heat carrier .....	18		
5.4 Pressure differential diagram for			
CTC EcoAir 600 .....	19		
<b>6. Electrical installation</b> .....	<b>20</b>		



### Quick reference

Fill in the information below. It may come in useful if anything should happen.

Product:	Manufacturing number:
Installer:	Name:
Date:	Tel. no.:
Electrical installer:	Name:
Date:	Tel. no.:

No liability is accepted for any misprints. We reserve the right to make design changes.

# Safety instructions



Turn off the power with an omnipolar switch before doing any work on the product.



The product must be connected to protective earth.



The product is classified as IP X4.



When handling the product with a hoist ring or similar device, make sure that the lifting equipment, eyebolts and other parts are not damaged. Never stand under the hoisted product.



Never jeopardise safety by removing bolted covers, hoods or similar.



Never jeopardise safety by deactivating safety equipment.



Any work on the product's cooling system should be carried out by authorised personnel only.



The product's electrical systems should only be installed and serviced by a qualified electrician.

-If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



This device can be used by children from the age of eight years and above and by people with reduced physical, sensory or mental ability or lack of experience or knowledge if they have been taught, either with supervision or with the instructions provided, how to use the device safely and understand the risks involved. Children should not play with the device. Cleaning and maintenance should not be carried out by children without supervision.



If these instructions are not followed when installing, operating and maintaining the system, Enertech's commitment under the applicable warranty terms is not binding.



Information in this type of box [!] is particularly important for correctly installing and using the product.

Regulus provides the information with reservation for any typing errors and subject to modification.

# Checklist

The check list must be completed by the installer.

- If service is needed, you may be required to provide this document.
- Installation must always be done according to the installation and maintenance instructions
- Installation must always be carried out in a professional manner

**Following installation, the unit must be inspected and functional checks performed as indicated below:**

## Pipe installation

- Heat pump filled, positioned and adjusted in the correct manner according to the instructions.
- The heat pump should be positioned so that it can be serviced
- Capacity of the charge/radiator pump (depending on type of system) for the flow required.
- Open radiator valves (depending on type of system) and other relevant valves.
- Tightness test
- Bleed the system
- Check proper operation of the requisite safety valves
- Action taken to deal with condensation water

## Electrical installation

- Power switch
- Correct tight wiring
- Requisite sensors fitted
- Heat pump activated and started
- Accessories

## Information for the customer (adapted to current installation)

- Start-up with customer/installer
- Menus/controls for selected system
- Installation and maintenance manual supplied to the customer
- Check and filling, heating system
- Information on fine adjustments
- Alarm information
- Functional test of safety valves fitted
- Information on procedures for fault registration

---

Date / Customer

---

Date / Installer



# The Complete System



## CTC EcoAir 614M / 622M

CTC EcoAir 600 (614M / 622M) is a modulating air source heat pump which transfers heat from the outside air to the property's heating system. The heat pump works with outside air temperatures as low as -22 °C.

CTC EcoAir 600 is designed to operate with high efficiency and low noise levels. The heat pump has integrated, on-demand hot gas defrosting which keeps the evaporator coil free from ice in order to maintain high efficiency.

## Control

CTC EcoAir 600 can be controlled by either of these products.

- IR 14
- RegulusBOX
- RegulusHBOX

## Charge pumps

A circulation pump is included in supply of a RegulusBOX / RegulusHBOX. A system with no indoor unit shall be equipped with a CSE TC W-PWM pump station (code 17868).

Energy labeling decals can be downloaded at <https://www.regulus.eu/en/energy-labelling>.

# 1. Technical data

		EcoAir 614M	EcoAir 622M
Product Code:		17156	17157
Electrical data		400 V 3N~ 50Hz	400 V 3N~ 50Hz
Input power <sup>1)</sup>	kW	0.54 / 3.94	0.94 / 6.03
Output power <sup>1)</sup>	kW	2.55 / 8.69	4.75 / 13.99
COP <sup>1)</sup>		4.71 / 2.21	5.07 / 2.32
Rated current <sup>2)</sup>	A	10.2	16.9
Rated current with temp. limit.	A	9.4	15.5
Max start current	A	2.7	4.9
Water volume	liter	1.9	2.8
Refrigerant quantity R407C, fluorinated greenhouse gases GWP 1774 <sup>4)</sup>	kg	2.2	2.7
CO <sub>2</sub> equivalent	ton	3.903	4.790
Max/min system temperature	°C	65/15	65/15
Max/min system pressure	MPa (bar)	0.25/0.05 (2,5/0,5)	0.25/0.05 (2,5/0,5)
High pressure switch HT	MPa (bar)	3.1 (31)	3.1 (31)
Max/min temp. (TS) (PED)	°C	100/0	100/0
Max/min pressure (PS) (PED)	MPa (bar)	0.3/0 (3.0/0)	0.3/0 (3.0/0)
Dimensions (Depth x Width x Height)	mm	545 x 1245 x 1080	645 x 1375 x 1180
Compressor / Oil type		Inverter scroll / PVE FV50S	Inverter scroll / PVE FV50S
Air flow 100%	m <sup>3</sup> /h	3129	5457
Fan speed	rpm	Modulating	
Fan, max power	W	54	148
Weight (packaged weight)	kg	174 (204)	192 (226)
Sound power in accord. w. ecodesign <sup>3)</sup>	dB(A)	51/52	55/55
Ingress Protection (IP)		IP X4	IP X4

<sup>1)</sup> At 35°C water temperature. +7 @ min rps / -7 °C @ max rps. According to EN 14511.

<sup>2)</sup> At max rps incl. Grundfos UPM GEO 25-85 charge pump.

<sup>3)</sup> Sound power level in accordance with EN12102 appendix A.4 i at test conditions A7 W47/55 and A7 W30/35


No annual leakage control of the refrigerant is required.

**!** Note: In case of deviations, the product's data plate applies. When servicing always check the product's data plate for correct refrigerant quantity.

## 1.1 Sound pressure data

	Sound power	Sound pressure 5 m	Sound pressure 10 m
EcoAir 614M	52 dB(A)	33 dB(A)	27 dB(A)
EcoAir 622M	55 dB(A)	36 dB(A)	30 dB(A)


## 1.2 Dimensions diagram



	CTC EcoAir 614M	CTC EcoAir 622M
A	486	550
B	1155	1285
C	1245	1375
D	188	188
E	1080	1180
F	308	308
G	476	476
H	451	551
I	Ø28	Ø28
J	85	83
K	545	645
L	10	33

## 1.3 Refrigerant system


Refrigerant system CTC EcoAir 600



## 1.4 Operating range


The control system for CTC EcoAir 600 monitors and ensures that the product functions within its operating range.

Primary flow C°




## 1.5 Component location

Component location  
CTC EcoAir 614M / 622M




### Configuration of coils:

- ① AC coil: EcoAir 614M
- ②⑨ DC coil: EcoAir 622M




Schematic diagram  
CTC EcoAir 614M / 622M



- |                                       |  |
|---------------------------------------|--|
| 1. AC coil                            | 17. Bleeding nipple/water  |
| 2. Fan                                | 18. Expansion valve  |
| 3. Frequency converter                | 19. Connection box   |
| 4. Defrosting sensor in evaporator    | 20. Communication  |
| 5. Type plate with serial number etc. | 21. Discharge sensor   |
| 6. Compressor                         | 22. Communication product  |
| 7. High pressure switch               | 23. Outdoor sensor   |
| 8. Suction gas sensor                 | 24. Feeding product  |
| 9. High pressure sensor               | 25. Serial number  |
| 10. Compressor heater                 | 26. Evaporator   |
| 11. 4-way valve                       | 27. Primary flow Ø28 mm  |
| 12. Drying filter                     | 28. Return flow Ø28 mm   |
| 13. Return sensor                     | 29. DC coil  |
| 14. Condenser                         | 30. Packaged components (filter ball valve and condensate drain) in cardboard box under product on pallet. |
| 15. Low pressure sensor               |  |
| 16. Primary flow sensor               |  |

## 2. Connection alternatives



## 3. Important to remember!

Check the following points in particular at the time of delivery and installation:


### 3.1 Transportation

- The product must be transported and stored in an upright position. Transport the unit to the installation site before removing the packaging.
- Remove the packaging and check before installation that the product has not been damaged in transit. Report any transport damage to the carrier.
- Move the product with a forklift if possible, or with lifting straps tied around the pallet. NB: Can only be used with the packaging on.

MIND THE DIFFERENT WEIGHT OF THE RIGHT AND LEFT PARTS OF THE HEAT PUMP!

### 3.2 Positioning

- Place the product on a solid foundation; see chapter "Placement of the heat pump".
- Flexible hoses should be installed closest to the heat pump. Outdoor pipes should be thoroughly insulated with weather-proof insulation.
- Ensure that pipes used between the heat pump and the heating circuit are of adequate dimensions.
- Ensure that the circulation pump has sufficient capacity to pump the water to the heat pump.



### 3.3 After commissioning

- The installation engineer advises the property owner on the construction and servicing of the system.
- The installation engineer fills in a checklist and contact information – the customer and installation engineer sign the list, which the customer keeps.



## 4. Installation

This section is aimed at anyone responsible for one or more of the installations required to ensure that the product works the way the property owner wants.

Take your time going through functions and settings with the property owner and answer any questions. Both you and the heat pump benefit from a user who has completely understood how the system operates and should be maintained.

The installation must be carried out in accordance with current standards.

### 4.1 Delivery includes:


- 1 x Heat pump CTC EcoAir 600
- Packaged components (see chapter titled 'Component Location')
- 15 m cable LiYCY (TP 2x2x0.75 mm<sup>2</sup>) with connector for communication, fitted.
- 2 m power cable, fitted:

CTC EcoAir 614M	CTC EcoAir 622M
5G x 2.5 mm <sup>2</sup>	5G x 4 mm <sup>2</sup>

## 4.2 Placement of the heat pump

- CTC EcoAir 600 should be mounted as usual on an outside wall.
- There should be a space of at least 300 mm (EcoAir 614M) or 400 mm (EcoAir 622M) between the heat pump and the wall so that outdoor air can pass freely in through the evaporator.
- Allow a space of at least 2 metres between the heat pump and any bushes etc.
- Place the heat pump in a way that prevents noise from the compressor and fan disturbing the surroundings.
- Do not place the heat pump right next to a bedroom window, patio or fence.
- Take the distance to the nearest neighbour into account by studying the sound data in the chapter titled 'Technical Data'.
- The stand must stand stably on concrete blocks or similar.
- Use a spirit level to adjust the unit, so that it is completely level.
- Due to the design of the stand and the weight of the pump, it is not necessary to mount the unit to the ground or the wall.
- Should the heat pump be placed in an open area (e.g. on a roof), place it sidewise to the prevailing wind direction, or provide sufficient wind protection in another suitable way. Strong wind flowing through the heat pump heat exchanger reduces its COP and may cause problems when defrosting the heat exchanger fins.
- The heat pump must not be installed in a covered area, nor in an outbuilding or carport, because the air should flow as freely as possible through the heat pump and used air should not to be sucked into the inlet on the back. This can cause abnormal ice formation in the evaporator.
- If the product is placed in an area where it will be subjected to particularly harsh weather conditions, the product can be installed underneath a small awning.
- The heat pump has a factory-fitted condensation water tray from which condensation water is conducted to a caisson, surface water drain, downpipe or other drainage equipment. You should therefore consider the position of the product.
- If the condensation water pipe is not used, the foundation must be such that condensing water and melted snow can drain into the ground. Make a 'stone curb' under the heat pump. Remove 70–100 cm and fill up with crushed stones to obtain the best possible drainage.

**!** These guidelines must be followed in order for your CTC EcoAir 600 to perform optimally




## 4.3 Preparation and drainage

The heat pump should be positioned so that the house cannot be damaged and the condensation water can easily drain into the ground. The foundation should be of concrete blocks or similar, resting on crushed stones or gravel.

- Make a 'stone curb' under the heat pump. Remember that there may be up to 70 litres of condensation water a day under some conditions.
- Dig a hole in the ground 70-100 cm deep.
- Place a moisture barrier in the hole on the side against the foundations of the building
- Half fill the hole with crushed stones and lay concrete blocks or similar.
- Mark the \*centre-to-centre (c.t.c) distance between the blocks for the heat pump stand.


*c.t.c distance	CTC EcoAir 614M	CTC EcoAir 622M
length (depth) mm	1155 (452)	1285 (552)

- Use a spirit level to ensure that the blocks are level.
- Place crushed stones around the blocks to achieve optimal drainage.



## 4.4 Condensation water

- The condensation tray is built into the heat pump and is used to divert most of the condensation water. The tray can be connected to a suitable drain. Connection diameter: 42 mm.
- A heating cable (available as an accessory) should be placed in the pipe to prevent refreezing. The heating cable is connected to the electrical cabinet on the heat pump. (Must be performed by an authorised electrician and according to applicable provisions.)
- If the house has a cellar, it is advisable to route the condensation water to a floor drain indoors (to be performed according to the applicable rules). The pipe should be installed with a slope towards the house and above the ground (so no other water can get into the cellar). Wall apertures should be sealed and insulated. A water trap must be connected to the inside to prevent air from circulating in the pipe.
- If there is a stone curb, the outlet from the condensation water pipe should be placed at a frost-free depth.
- The condensation water can also be conducted to the building's drainage, e.g. downpipe drains. Here a heating cable must be placed in the pipes that are not frost-free.



## 5. Pipe installation


The installation must be carried out in accordance with current standards. The boiler must be connected to an expansion vessel in an open or closed system. Do not forget to flush the heating circuit clean before connection.

### 5.1 Pipe connection

- We recommend connecting a pipeline with a minimum of Ø28 mm copper tubing to the heat pump.
- Route the pipes between the heat pump and the boiler without any highest points. If this cannot be done, provide this highest point with an automatic air separator or an in line aerator.
- The connection to the heat pump should be made with a wire-reinforced, impermeable hose for hot water, minimum 1" (available as an accessory). Minimum hose length 600 mm to prevent noise from the heat pump entering the building and to absorb any vibration in the heat pump.
- Pipes installed outside should be insulated with at least 19 mm thick pipe insulation which is not sensitive to water. Ensure that the insulation is sealed tightly everywhere and that joints are thoroughly taped or glued.
- Indoor pipes should be insulated all the way to the boiler with at least 13 mm thick insulation. This is to enable the heat pump to deliver the highest possible temperature to the boiler or tank without any losses.
- The product can be bled via the bleed valve inside the condenser.

**NOTE! Only bleed this valve. Other valves are for the cooling system! If these are opened, refrigerant may leak out!**

**!** If necessary, the radiator systems should be flushed clean before connecting.



## 5.2 Circulating pump – heat carrier

The pump transports the heat from EcoAir to CTC EcoZenith. If the outdoor temperature is below +2°C the pump runs constantly to eliminate any risk of freezing.

If the product is installed at a facility where power outages can occur, then it is advisable to supplement with an emergency power generator for the charge pump. It is also possible to install mechanical frost protection.

The product is used for control monitors and ensures that the heat pump works within its operating range.

### Setting the temperature differential

For external control, a circulation pump is installed so that the right flow through the heat pump can be guaranteed.

Set the right temperature differential by adjusting the speed of the circulation pump. This is to ensure that the right differential for the current outdoor temperature is produced according to the table.


Outdoor temp. (°C)		-10	-5	0	+5	+7	+10
CTC EcoAir 614M	Primary flow 35 °C Flow = 760 l/h (0.21 l/s)	4 °C	4.5 °C	5.5 °C	6.5 °C	7 °C	8 °C
CTC EcoAir 622M	Primary flow 35 °C Flow = 1400 l/h (0.39 l/s)	4 °C	5 °C	6 °C	6.5 °C	7 °C	8 °C

In some systems, the full radiator flow goes through the heat pump, which means the pump must be sized according to the flow of the whole system. For safe operation, the following flows should be considered:

- 760 l/h (0.21 l/s) pro CTC EcoAir 614M
- 1400 l/h (0.39 l/s) pro CTC EcoAir 622M.

This provides a temperature differential of approx. 7 °C for an outside temperature of +7 °C and a primary flow temperature of 35 °C.

### 5.3 Pressure differential diagram for CTC EcoAir 600



## 6. Electrical installation

### 6.1 General information, electrical connections



Installation and heat pump connection must be performed by an authorised electrician. All wiring must be installed according to applicable provisions. Before the front panel is opened or other live components are made accessible, the power supply to the heat pump must be fully disconnected.

CTC EcoAir 614M/622M must not be powered through CTC EcoZenith i250.

#### Omnipolar safety switch

The installation should be preceded by an omnipolar safety switch according to overvoltage category III, which ensures disconnection from all electric power sources.

Even if a residual current device is used, CTC EcoAir must still be fitted with its own residual current device with on/off delay.

### 6.2 Electric installation 400 V 3N~

CTC EcoAir 600 must be connected to 400 V 3N~ 50 Hz and protective earth.

The 2 m long power supply cable is pre-connected to the product.


### 6.3 Compressor heater

The compressor heater automatically heats up when the compressor is cold.

The compressor heater is pre-connected on delivery.

### 6.4 Heat pump connections

When installing a heat pump, make sure DIP switch 2 is in the ON position on the last heat pump in the series connection (factory default).






## 6.5 Series connection of CTC EcoAir 600


### 6.5.1 Series connected heat pump connections

When connected in series, DIP switch 2 must be set to OFF for all heat pumps, except for the last pump, which must be set to "ON".


From the communication viewpoint, the order of the heat pumps is not important. What is important is that each pump has its own unique number between A1 and A10.





#### Heat pumps in series connection



#### The last heat pump connected in series




## Shield connection diagram



## 6.6 Alarm output


The CTC EcoAir 600 is fitted with a potential-free alarm output which is activated if any alarm is active in the heat pump. This output may be connected to a maximum load of 1 A 250 V AC. A cable approved for 230 V AC must be used for connecting this output, irrespective of the load that is connected. For connection information, see the wiring diagram.




Close-up from wiring diagram.



## 6.7 Wiring diagram 400 V 3N~ (A3)





## 6.9 Parts list

A1	Display (CTC EcoZenith i250/i350)	
A2	Relay/main card (IR14)	
A5	HP control card	
A10	Frequency converter	
B1	Primary flow sensor	Type 2 NTC
B7	Return sensor	Type 2 NTC
B15	Outdoor sensor	Type 1 NTC
B16	Defrosting sensor	Type 1 NTC
B20	Fan air sensor	Type 1 NTC
B21	Discharge sensor	Type 3 NTC
B22	Suction gas sensor	Type 1 NTC
B100	High pressure sensor	
B101	Low pressure sensor	
C1	Condenser compressor (1-phase)	
C2	Condenser	
E10	Compressor heater	
E11	Condenser tray heater	
E12	Heating cable (option)	
F1	Fuse (option)	
F11	Omnipolar switch	
F20	High pressure switch	
L1	Spool	
M1	Compressor	
M10	Fan	
X1	Terminal block	
XM1	Connector supply Male	
XM2	Connector supply Female	
XC1	Connector compressor Male	
XC2	Connector compressor Female	
Y10	Expansion valve	
Y11	Solenoid valve	
Z1	EMC filter	

## 6.10 Sensor Data

Temperature °C	Sensor Type 1 NTC kΩ	Temperature °C	Sensor Type 2 NTC kΩ	Temperature °C	Sensor Type 3 NTC kΩ
100	0.22	100	0.67	130	5.37
95	0.25	95	0.78	125	6.18
90	0.28	90	0.908	120	7.13
85	0.32	85	1.06	115	8.26
80	0.37	80	1.25	110	9.59
75	0.42	75	1.47	105	11.17
70	0.49	70	1.74	100	13.06
65	0.57	65	2.07	95	15.33
60	0.7	60	2.5	90	18.1
55	0.8	55	3.0	85	21.4
50	0.9	50	3.6	80	25.4
45	1.1	45	4.4	75	30.3
40	1.3	40	5.3	70	36.3
35	1.5	35	6.5	65	43.6
30	1.8	30	8.1	60	52.8
25	2.2	25	10	55	64.1
20	2.6	20	12.5	50	78.3
15	3.2	15	15.8	45	96.1
10	4	10	20	40	119
5	5	5	26	35	147
0	6	0	33	30	184
-5	7	-5	43	25	232
-10	9	-10	56	20	293
-15	12	-15	74	15	373
-20	15	-20	99	10	479
-25	19	-25	134	5	619
-30	25	-30	183		

## 7. First start

1. Check that the boiler and system are full of water and have been bled.
2. Check that all connections are tight.
3. Check that sensors and the charge pump are connected to the power source.
4. Energise the heat pump by switching on the operating switch (the main switch).

Once the system has heated up, check that all connections are tight, the various systems have been bled, heat is coming out into the system and warm water is coming out at the tap locations.

## 8. Operation and Maintenance

When the installer has installed your new products, you should check along with the installer that the system is in perfect operating condition. Let the installer show you where the power switches, controls and fuses are so that you know how the system works and how it should be maintained. Bleed the radiators (depending on type of system) after around three days of operation and top up with water if required.

### Defrosting

CTC EcoAir 600 is fitted with hot gas defrosting. The heat pump checks constantly whether defrosting is needed and, if so, defrosting starts, the fan stops, the 4-way valve changes direction and the discharge goes to the evaporator instead. A hissing sound is heard as the water drains from the evaporator. There may be large amounts of water. When the product has defrosted, the fan starts and the discharge goes into the condenser instead, and the heat pump returns to normal operation.

### Modulating compressor

The power in the heat pump is adapted using modulating operation according to the actual energy requirement. The compressor runs constantly with the correct power and thereby minimises the number of start and stop periods. The modulating power regulation provides optimal efficiency.

### The fan

The fan starts 15 seconds before the condenser and runs until the compressor stops. During defrosting the fan stops and restarts when defrosting is finished. The fan is speed-controlled and follows the need for power.

### Maintenance

A large amount of air passes through the evaporator. Leaves and other debris can get stuck and restrict the air flow. At least once year the evaporator coil should be checked and cleared of particles that block the air flow. The evaporator and outer covering should be cleaned with a damp cloth or soft brush. No other periodic maintenance or inspection is necessary.



## Periodic maintenance

After three weeks' operation and then every three months during the first year. Then once a year:

- Check that the installation is free of leaks.
- Check that the product and system are free of air; bleed if needed.
- Check that the evaporator is clean.
- The products do not require annual inspection for refrigerant leakage.


## Operation stop

The heat pump is switched on/off by its controller. If switching off is needed due to e.g. servicing, the heat pump is shut down using the operating switch. If there is a risk of the water freezing, ensure that there is circulation, or drain out all the water from the heat pump.

## Condensation water tray

The condensation water tray collects water formed on the EcoAir's evaporator during operation and defrosting. The condensation water tray is equipped with an electric heating coil which keeps the tray free of ice when it is freezing outside. The condensation water tray is located at the bottom on the back of EcoAir. By lifting the handle on the cover plate and pulling it out, you can clean and inspect the condensation tray.

As an accessory you can buy a heating cable to connect to EcoAir. The cable is fitted in the drain from the condensation tray to the frost-free drain.



Condensation tray and drain

## 9. Troubleshooting/appropriate measures

CTC EcoAir 600 is designed to provide reliable operation and high levels of comfort, and to have a long service life. Various tips are given below which may be helpful and guide you in the event of an operational malfunction.

If a fault occurs, you should always contact the installer who installed your unit. If the installer believes the malfunction is due to a materials or design fault, then they will contact CTC AB to check and rectify the issue. Always provide the product's serial number.

### Air problems

If you hear a rasping sound from the heat pump, check that it is properly bled. Top up with water where required, so that the correct pressure is achieved. If this noise recurs, call a technician to check the cause.

### Alarms

Any alarms and information texts from CTC EcoAir 600 are displayed in the product which is used to control it; you should therefore consult the manual of that product.

### Circulation and Defrosting

If the circulation between the indoor and the outdoor unit is reduced or stops, the high pressure switch is triggered. Possible reasons for this:

- Defective circulating pump/Circulating pump too small
- Air in the pipes
- Condenser reset
- Other intermediate obstructions to the water flow

During defrosting the fan stops but the compressor operates and the melted snow and ice flows into the condensation tray under the heat pump. When defrosting stops, the fan starts again and initially a vapour cloud, consisting of damp air which condenses in the cold outdoor air, is created. This is perfectly normal and stops after a few seconds. If the pump heats poorly, check that no unusual ice formation has occurred. Possible reasons for this:

- Defective defrosting automation
- Lack of refrigerant (leakage)
- Extreme weather conditions.

# EU Declaration of conformity



## CTC EcoAir 610M / 614M / 622M

Outdoor modules  
art no. 588402001, 588400001, 588401001

This declaration of conformity is issued under the sole responsibility of the manufacturer.  
The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:

**Low Voltage Directive (LVD) 2014/35/EC**  
**Electromagnetic Compatibility (EMC) 2014/30/EC**  
**Restriction of the use of certain hazardous substances (RoHS) Directive 2011/65/EC**  
**Ecodesign Directive 2009/125/EC**  
 regulations (EU) 811/2013, 813/2013  
**Pressure Equipment Directive (PED) 2014/68/EC, Module A**

References to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared:

LVD	EN 60335-1:2017+ A11:2014	Household and similar electrical appliances - Safety - ...General requirements
LVD	EN 62233:2008	Measurement methods for electromagnetic fields...
EMC	EN 55014-1:2007+ A1:2009+ A2:2011	...Requirements for household appliances, electric tools and similar apparatus - Emission
EMC	EN 55014-2:1997+ A1:2001+ A2:2008	- " " -Immunity..
EMC	EN 61000-3-2:2014	...Limits for harmonic current emissions...
EMC	EN 61000-3-11:2000	...Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems...
EMC	EN 61000-3-12:2011	...Limits for harmonic currents produced by equipment connected to public low-voltage systems...
EMC	EN 61000-4-2:2009,-3:2006+ A1:2008+ A2:2010,-4:2012,-5:2014,-6:2014,-11:2004	...Testing and measuring techniques...
RoHS	EN 50581:2012	Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances
PED	EN 378:2016-1, -2	Refrigerating system and heat pumps -Safety and environmental requirements
Ecodesign	EN 14511-1, -2, -3, -4:2013	Air conditioners, liquid chilling packages and heat pumps with electrically driven compressors for space heating and cooling
Ecodesign	EN 14825:2013	...Testing and rating at part load conditions and calculation of seasonal performance
Ecodesign	EN 12102:2013	...Determination of the sound power level

Additional information:

CE marking was affixed 2018

Signed for and on behalf of:



**Enertech AB**  
Box 313  
S-341 26 LJUNGBY

Ljungby 2018-06-19

**Joachim Carlsson**

Technical Manager

Ljungby 2018-06-19

**Ola Karlsson**

Quality Manager

