

Regulus

www.regulus.cz

Evropský patent
č. 0630426

ACES



Návod na instalaci a použití

ACES
Antikorozní elektronický systém

CZ

CE

ACES

INOVOVANÝ KATODOVÝ OCHRANNÝ SYSTÉM PRACUJÍCÍ POMOCÍ ELEKTRICKÉHO PROUDU, PRO ZÁSOBNÍKY TV

Tradiční antikorozní systém, který se běžně používá u průtokových a zásobníkových ohřívačů TV, sestává z použití nerezové oceli, nebo vnitřní povrchové ochrany (např. smalt, teflon) a užití hořčíkových anod.

Tento systém má však dvě hlavní nevýhody:

- Pasivní ochrana, kterou poskytuje vnitřní povrchová úprava zásobníku, je často neúplná. Drobné vady, i když vyhovují normě DIN 4753, díl III ($7 \text{ cm}^2/\text{m}^2$), způsobují snížení účinnosti.
- Hořčíkové anody se spotřebují a tudíž je nutná častá kontrola a případná výměna.

Nový systém


Současná technika, kombinující použití elektroniky s nejnovějším výzkumem v oblasti chování elektrochemických proudů, vedla k vývoji nového antikorozního elektronického systému (ACES), který poskytuje elektronickou ochranu proti korozi.

Systém ACES nabízí řadu unikátních funkcí:

- Aktivní ochrana pomocí elektrického proudu z vnějšího zdroje
- Značný stupeň provozní pružnosti: systém se adaptuje na změny ve stavu vnitřní povrchové vrstvy a na kvalitu vody pomocí automatické regulace intenzity elektrického proudu.
- Trvalá ochrana bez nutnosti pravidelných kontrol a údržby.
- ACES chrání kotle a průtokové a zásobníkové ohřívače TV před korozí, čímž uživateli šetří starosti a náklady.

Technická specifikace

stupeň elektrického krytí	IP 55
provozní teplota okolí	0-40 °C
připojovací síťový kabel	s plochou zástrčkou (délka 1,9 m)
výstupní nízkonapěťový kabel	s konektorem (délka 1,9 m)
držák anody	UNI-ISO 7/1-R1/2"
anoda	průměr 3 mm z upraveného titanu
napájecí napětí	230 V ± 10 % - 50/60 Hz
max. výstupní napětí	18 V
max. výstupní proud	0,18 A
max. příkon	2,5 W
celkové rozměry generátoru	60 × 52 × 45 mm
hmotnost	÷ 0,4 kg



Princip činnosti

Antikorozní katodový přístroj ACES generuje stejnosměrný proud, který udržuje potenciál elektrolytu na optimální úrovni pomocí regulace intenzity proudu mezi anodou a katodou (plášť zásobníku). Rozdíl potenciálu mezi pláštěm a titanovou anodou je trvale měřen, na případné změny reaguje přístroj během mikrosekund a okamžitě tyto změny vyrovnává. Základní charakteristika umožňuje použití jediné anody, která přenáší proud do vody a určuje potenciál.

Popis přístroje

Anoda se skládá z titanového jádra s aktivním koncem a je upevněna do zátky s $\frac{1}{2}$ " závitem. Použití ušlechtilých kovů, aktivovaných patentovaným procesem, zaručuje účinný chod a prodlužuje životnost nádrže. Generátor je umístěn v nehořlavé, žáruvzdorné krabici z pryskyřice Noryl.

Systém ACES je jednoduchý na použití a může být instalován do nejrůznějších průtokových a zásobníkových ohříváčů TV o různých objemech.

Instalace a provoz

Kontrolka LED umístěná vepředu na krabici indikuje stav přístroje: zelené světlo znamená, že přístroj je v bezchybném provozním stavu. Červené znamená, že se jedná o poruchový stav, a že je potřeba nejdříve odpojit přístroj od sítě. Pokud je zásobník prázdný, je nutné doplnit vodu, nebo je zapotřebí upravit polohu anody. Anoda se nesmí dotýkat žádné kovové části zásobníku, protože by mohlo dojít ke krátkému spojení a následnému poškození přístroje. Doporučuje se umístit aktivní (tj. tmavou část) anody do geometrického středu nádoby. Žádná část anody se nesmí čistit, protože hrozí její poškození.


Při instalaci se nedotýkejte aktivního povlaku a zabraňte jeho poškození nebo znečistění.

Při instalaci je nezbytné dodržovat správnou polaritu: kabel, který je ukončen konektorem-samičkou se napojí na anodu (+), zatímco kabel, který je ukončen očkem se spojí s uzemněním zásobníku (-). V zásobníku nesmí zůstat žádná hořčíková anoda.

Pokud výše uvedené zapojení nebude dodrženo, záruka nebude uznána.

Umístění anod v zásobníku


1. Sada s jednou anodou



2.Sada se dvěma anodami


Pokud sada obsahuje anody různých délek, umístěte delší anodu shora do zásobníku a kratší do příruby.

U zásobníků RBC HP vyjmout Mg anodu a zaslepit zátkou G5/4"



3.Sada se třemi anodami

Nejkratší anodu umístěte do příruby zásobníku.



Použití v závislosti na objemu nádoby

Maximální objem nádoby, kterou lze takto úspěšně ochránit, závisí na použitém materiálu (nerez, ocel) a na stavu vnitřní povrchové úpravy (smalt, plast. povlak atd.). Pokud je vnitřní povlak v dobrém stavu a topný prvek nebo výměník je izolován, proud produkovaný generátorem dostačuje k ochraně zásobníků o kapacitě až do 5000 litrů.

Pro zásobníky větší než 5000 litrů je třeba použít dva nebo více generátorů.



Proces katodové antikorozní ochrany pomocí generátoru ACES a generátor sám jsou chráněny evropským patentem č. 0630426.

Výrobce si vyhrazuje právo kdykoli produkt modifikovat bez předchozího upozornění.

Graf potenciálu ochrany měřený v souladu s DIN 4753.

Testy provedeny na smaltovaném zásobníku TV o objemu 500 litrů s přípravou teplé vody elektrickým topným tělesem, s ochranou ACES.

ACES, smontovaný s kably a dvěma, třemi anodami.



ZÁRUČNÍ LIST

Typ:

Výrobní číslo:

Prodejce:

Datum prodeje:

ZÁRUČNÍ PODMÍNKY

1. Prodávající poskytuje kupujícímu na výrobek záruční dobu v trvání 24 měsíců od data prodeje.
2. Při uplatnění záruky předložte rádně vyplněný záruční list a doklad o zakoupení výrobku.
3. Podmínkou záruky je dodržení technických podmínek výrobce, návodu k montáži a k použití a pokynů uvedených v průvodní dokumentaci výrobku, jakož i na výrobku samotném.
4. Záruka se nevztahuje na závady způsobené vnějšími vlivy nebo nevhodnými provozními podmínkami, dále když není výrobek užíván v souladu s jeho určením, na závady vzniklé běžným opotřebením, když k závadě výrobku došlo mechanickým poškozením, nesprávnou obsluhou, neodborným zásahem třetí osoby, neodbornou instalací, nevhodným skladováním, živelnou pohromou, atd.

- The warranty period is 24 months from the date of purchase.
- When claiming warranty, this Warranty Certificate must be submitted together with the purchase receipt.
- The warranty is valid only when the technical conditions set by the Manufacturer, installation manual and instructions in the documentation and on the product itself are maintained.
- The warranty does not cover defects caused by extreme conditions or improper operation conditions, defects caused by usual wear and tear, further when the product is not used in compliance with its purpose and when the defect was caused by mechanical damage, improper handling, tampering by a third person, improper installation, improper stocking, natural disaster etc.

WARRANTY CONDITIONS

Seller: Date of purchase:

Serial Number:

Type:

WARRANTY CERTIFICATE

The manufacturer reserves the right to modify the product at any time without prior notice.

The cathodic anti-corrosion process provided by the ACES generator and the generator itself are covered by European Patent No. 0630426.



For tanks over 5000 l two or more generators should be installed.


The maximum capacity of the tank to be successfully protected depends on the material used (stainless-steel, steel) and on the condition of the internal lining (enamel, plastic coating, etc.). If the internal lining is in good condition and the heating element or heat-exchanger is insulated, the current produced by the generator is sufficient to protect tanks with a capacity of up to 5,000 liters.

The right use depending on the tank volume


ACES, assembled with cables and two, three anodes.

Protection potential chart measured according to DIN 4753. Tests were carried out on an enamelled 500 l hot water storage tank with DHW heating by an electric heating element, protected by ACES.






Place the shortest anode rod into the flange of the HW tank.
3. Set with three anode rods



If the set involves rods of different lengths, place the longer one from the top into the hot water tank and the shorter into the flange. In RBC HP hot water tanks, the magnesium anode rod shall be removed and the opening plugged with a G5/4" plug.
2. Set with two anode rods

In RBC HP hot water tanks, the magnesium anode rod shall be removed and the opening plugged with a G5/4" plug.



1. Set with one anode rod

Placement of the anode rods in a hot water tank

Failure to respect the above described wiring will make the warranty null and void.

anode rod may remain in the tank.

When installing an anode rod, its proper polarity must be maintained: the cable with the female connector shall be connected to the anode (+) while the cable with the eyelet shall be connected to the tank ground (-). No magnesium anode rod may remain in the tank.

When installing the anode, do not touch its active coating and protect it from damage or contamination.

Working conditions. The red light means a defect and it is necessary to unplug power supply cable. If the tank is empty, it shall be repelished with water or the anode must not touch any metal part of the tank as it could cause short circuit and subsequent damage to the device. It is recommended to place the active section of the anode (the dark one) into the geometric center of a tank. No anode cleaning is permitted as it might get damaged.

Installation and Operation


The ACES system is simple to use and can be fitted to a wide range of instantaneous water heaters and hot water storage tanks of various capacities.

The anode consists of a titanium core with an activated tip, fitted to a 1/2" threaded plug. The use of noble metals, activated by a patented process, guarantees efficient operation and prolongs the service life of the tank. The generator is housed in a fireproof, heat-resistant casing in Novyl resin.

Description

The ACES cathodic anti-corrosion devices generate a direct current which maintains the potential of the electrolyte at an optimum level. The potential of the electrolyte is maintained at the optimum level by regulating the intensity of the current between the anode and the cathode (tank shell). The potential difference between the shell and the titanium anode is continuously measured, the device reacts to any changes within microseconds and immediately compensates for these changes. This essential characteristic makes it possible to use a single anode which transmits the current to the water and determines the potential.

How it works



IP rating	IP 55	
ambient working temperature	0-40 °C	
power supply cable	with flat plug (length 1.9 m)	
low voltage service cable	with faston connector (length 1.9 m)	
anode holder	UNI-IISO 71-R1/2"	
anode	3 mm diam. in treated titanium	
power supply	230V ± 10% - 50/60Hz	
max. output tension	18V	
maximum output current	0.18A	
max. power consumption	2.5W	
overall dimensions of generator	60x52x45mm	
weight	÷ 0.4kg	

Technical Specification

d) ACES protects boilers and hot water storage tanks against corrosion, saving thus costs and time.

c) Permanent protection, no regular checks and/or maintenance needed.

b) A high degree of operation flexibility: the system adapts itself to changes in the condition of the inner layer and to water quality through an automatic control of the el. current intensity.

a) Active protection by means of electric current from an external source.

ACES offers a wide range of unique functions:

State-of-the-art technology, combining the use of electronics with the latest research into the behaviour of electrochemical currents, has led to the development of the new Anti-Corrosion Electronic System (ACES) that provides electronic protection against corrosion.

The new system

b) Magnesium anodes are subject to deterioration, and must therefore be checked and replaced frequently.

lead to a reduction in efficiency.

imperfections, even if these are within the limits established by DIN standard 4753, part III (7sdcm/sqm),

a) The passive protection offered by the internal lining of the tank is frequently incomplete, since slight

However, this system has two major disadvantages:

An anticorrosion system traditionally used for instantaneous and water heaters storage hot water tanks is usually represented by using stainless steel or inner surface treatment (e.g. enamel or Teflon) and magnesium anodes.

ACES

CE

EN

Anti-Corrosion Electronic System
ACES
Installation and Operation Instructions



European Patent
No. 0630426

www.regulus.eu

Regulus

ACES